



Safety and Handling Guidelines for Light Tape®

- **NEVER** operate Light Tape® when in a coil. Unroll first before powering.
- **Always consult local electrical codes** for wiring or other specifications and regulations.
- Take care to mount the Light Tape® out of reach of children or malicious individuals.
- Always seal Light Tape® if cut with Light Tape® Edge Guard™.
- Do not step on Light Tape® during installation. Avoid hard creases.
- Do install in dry conditions. Do not cut or expose open ends to moisture.
- Do not break lamination when pulling around sharp edges or corners.
- Do not use a screwdriver or sharp object to force lamp into tight areas.
- Do not fold, twist, rotate or kink lamination excessively.
- Do not stretch, puncture or crease Light Tape®, as it will destroy conductive layers causing black spots or failure.
- Do not operate lamp outdoors during peak daylight hours.
- Do use for a photo-cell outdoor installation, to prevent the Light Tape® from operating in peak daylight hours.
- Do not operate Light Tape® without protective lamination.
- Do follow all installation guidelines from Electro-LuminX®. If there are any questions, check our web site, www.lighttape.com.
- Do not cut or puncture Light Tape®.
- Do not thermoform or stretch Light Tape® over objects, or bend Light Tape® in a tight radius.
- When cleaning Light Tape® or Smart Driver™ Lighting Ballasts, do not use water or chemical cleanser.
- Do not operate Smart Driver™ Lighting Ballasts outdoors unless in a NEMA enclosure.
- In industrial applications, use caution when operating Smart Driver™ Lighting Ballasts as they have not been explosion-proof rated by the National Electrical Code (USA, Central and South America), Canadian Standards Association, International Electrotechnical Commission (ATEX - Europe and outside Americas), and Gosstandart (Russia).